Alexa FAQ for Control4 Homeowners

Q: How do I connect an Amazon Alexa device to my Control4 Smart Home? **A:** Read the <u>Alexa Quick Start Guide</u>(ctrl4.co/alexa-help) or watch the <u>Connecting Amazon Echo to Control4</u> video (ctrl4.co/alexa-videohelp) to learn how to connect your Amazon Alexa device to your Control4 Smart Home.

Q: What Amazon Alexa devices will work with my Control4 Smart Home?A: The Amazon Echo, Echo Dot, Tap, and Fire TV with Voice Remote will all work with your Control4 Smart Home.

Q: Do all Control4 systems work with Alexa devices? **A:** You need a 4Sight subscription in order for your Control4 system to work with Alexa. Also, the system must be running OS 2.8.2 or greater.

Q: What devices in my Control4 Smart Home will I be able to control using voice commands?A: Initially, you can use voice commands for all your lights, lighting scenes and thermostats. You can control more items in your house by contacting your dealer to set up whole home scenes for you.

Q: Can I change the name of my device or scene for easier voice control?

A: Yes, log in to customer.control4.com and select Amazon Alexa under Devices. Here you can edit the device name for voice control. This will only change the name for voice control—all your touch panels, On-Screen Navigators, and Control4 apps for your mobile devices will have the original name. Details on this process can be found in the <u>Alexa</u> <u>Quick Start Guide</u>(ctrl4.co/alexa-help) or <u>Customizing Alexa devices and scenes</u> (ctrl4.co/alexa-scenehelp).

Q: In what countries can I use the Control4 Smart Home Skill?

A: You can use the Control4 Smart Home Skill in the USA, the UK, Ireland, and Germany.

Q: What voice commands can I use with my Control4 Smart Home?

A: Log in to customer.control4.com and select **View Voice Commands** to get a personalized list of commands you can use with your system. Below is a general sample of the commands you can use:

Lights

Turn on Kitchen Lights Turn off Kitchen Lights Set Master Lamp to 50% Increase Master Lamp by 10% Decrease Master Lamp by 20% **Thermostats** Set Upstairs Thermostat to 72 degrees Increase Upstairs Thermostat by 3 degrees Decrease Upstairs Thermostat by 2 degrees **Scenes** Turn on House Turn off House

Copyright ©2017, Control4 Corporation. All rights reserved. Control4, the Control4 logo, the 4-ball logo, 4Store, 4Sight, Control4 My Home, and Mockupancy are registered trademarks or trademarks of Control4 Corporation in the United States and/or other countries. All other names and brands may be claimed as the property of their respective owners. All specifications subject to change without notice. DOC-00241-C, 2017-09-05 MS



Q: Why are the changes I made on customer.control4.com not showing up in the Alexa app?A: After saving the changes on customer.control4.com, you need to ask Alexa to discover devices for them to show up in your Alexa app and be available.

Q: I disabled a device on customer.control4.com and asked Alexa to discover devices, but the disabled device is still showing in the Alexa app as offline. How do I get this removed from the Alexa app?

A: Go into the Alexa app and select **Forget** next to the disabled device and ask Alexa to discover devices again. If you have disabled multiple devices, you can press **Forget all devices and groups** and then ask Alexa to discover devices to get a clean list of devices.

Q: Are there any tips on naming devices or scenes?

A: It is best to use simple one- or two-word descriptions using house and room names where appropriate. For example: Dining Light, Office Lamps, All Lights, House, Upstairs Thermostat, Accent Lights, Master Lights.

Q: What names of devices or scenes should I not use?

A: Do not use numbers in device names like Kitchen 1 Light. Make sure each device and scene name is unique to your system and all names are spelled correctly. Avoid using On or Off as part of the device or scene name.

Q: Can I use more than one Alexa device with my Control4 System? **A:** Yes, they will all be able to accept the same voice commands but it is preferable to have them separated so that they do not hear the same voice commands.

Q: How does auto mode on the Control4 thermostat work with Alexa?

A: The Control4 thermostat has both a heat and a cool set point. When you ask Alexa to increase the temperature by two degrees or set the temperature to 72 degrees while in Auto mode the Control4 thermostat will do the following:

- If it is currently cooling the house, it will change the cool set point and check the heat set point to see if it needs to be adjusted.
- If it is currently heating the house, it will change the heat set point and check the cool set point to see if it needs to be adjusted.

Q: I created a lighting scene on my touch screen and everything worked. I then added another device to the lighting scene. Now, when I turn on the scene the added device turns on, but when I turn off the scene the added device does not turn off. How do I fix this?

A: If you add a device after you create a lighting scene, you will also need to add the device to the toggle lighting scene to have it turn off.

Q: Where do I go to get more information?A: More Information can be found at <u>ctrl4.co/alexa-help</u>.

Copyright ©2017, Control4 Corporation. All rights reserved. Control4, the Control4 logo, the 4-ball logo, 4Store, 4Sight, Control4 My Home, and Mockupancy are registered trademarks or trademarks of Control4 Corporation in the United States and/or other countries. All other names and brands may be claimed as the property of their respective owners. All specifications subject to change without notice. DOC-00241-C, 2017-09-05 MS

