



Control4® 4Sight® Service with Anywhere Access: Web Quick Reference


Control your home from the web while you're away

Welcome to the exciting world of home automation. Control your home remotely with Control4® 4Sight® Service and Anywhere Access: Web from any computer that has an Internet browser. Control everything in your system even when you're not at home. Turn on your TV in the family room for the kids while you're at the store. Not sure whether you've locked all of the doors when you left home? Simply check on your locks from the Internet to make sure everything's buttoned up.

Getting started

- 1 Before you can use the 4Sight Service with Anywhere Access: Web, you'll need to subscribe to the 4Sight Service (fee required). Your dealer can get you a 4Sight subscription. You'll also need a personal account on customer.control4.com. Use this account to access your home system from the web. If you don't have your account information, talk to your dealer.
- 2 Open an Internet browser from the device you are using.
- 3 Go to customer.control4.com and log in to your account.


- 4 Click **My House**.



- 5 Wait for the devices to connect, and your home system to load (depending on your OS):

- Pre-OS 2.0: HTML display only.
- OS 2.0-OS 2.4: HTML or Flash.
- OS 2.5 or later: Flash only.

- 6 Start controlling your system.



Select a room to control a device

If the interface shows that it's in a specific room, but you want to control a device in another room, change to the room where the device is. The current room's name appears at the top of your screen. This example shows the 'Family Room.'

- 1 Click the room's **name** at the top of the screen ('Family Room') to display the Change Rooms screen.
- 2 Click **House**, the **floor**, or the **room**. If a star appears next to the room, this indicates the default room. Let's select the **Entry Way**.


- 3 Notice that the room name changes to 'Entry Way.' Click what you want to control in that room.



Using 4Sight Service with Anywhere Access

Click an icon in the Home menu or room to control your system.

- 1 When you're in the room you want, click the icon you want.
- 2 Click what you want to control:



- 3 When you're finished using the browser, click in the upper-right corner of the account page to log out. Make sure you close the page.

Helpful tips

- **Room off.** Click the power button (see below) to turn off what is currently playing.
- **Listen**
 - Music services from Cable, Dish Network, and DirectTV are available.
 - You can access music stored on a PC or network storage using Listen > My Music.
 - Music services such as TuneIn display under Listen.
 - Radio stations display under the Listen > Stations button (depending on your reception and what you've set up).


Volume. To control audio, use the media bar (see below). Change the current room's volume, mute the music, power off, and more.



- A** **Currently Playing**—Lists the song currently playing.
- B** **Back**—Skips the song back.
- C** **Pause/Play**—Pauses or plays the song.
- D** **Forward**—Advances the song.
- E** **Mute**—Mutes the song.
- F** **Volume Controls**—Increases or decreases the volume by percentage.
- G** **Power**—Powers off what is currently playing.
- H** **Zones**—Enable or disable media zones. You can add zones from here or in Listen.

Zones. Click to enable or disable audio **zones** by room. For example, you can play music through the speakers in other zones by turning them on here. Accessing zones varies by device.

- Rooms (zones) currently off do not display, since no active devices are playing. To add a zone, start audio from any zone, and click **Add Rooms**. Adjust the volume (see below).
- Rooms are listed on the left by All Rooms, floor, and room (see below). Select the room, and then turn on or turn off the desired zone.




- **Watch**
 - If you or your dealer added favorites for your cable or satellite stations, you'll see your favorite channels in a folder. Click the folder and select the channel.
 - If you have a media player, you'll see a Movies button.
- **Comfort.** Thermostats appear in all rooms. Control your thermostats no matter which room you're accessing on the navigator.
- **Lighting.** Lists all of the installed Control4 lighting devices in your home, such as keypads, dimmers, switches, or lighting scenes (preprogrammed sets of lights you can control by room or activity).
 - Dimmers appear as slider bars where you can set light levels and intensity. Just click, hold, and slide the button.
 - Light switches appear as on/off toggles with no dimmer control. Just click the button **On** or **Off**.
 - Lighting scenes appear as a list of created scenes with specific names. Create, remove, or edit lighting scenes yourself.

All. Shows all lights and lighting scenes in the house.

By room. Shows the lights in a specific room.

Scenes. Shows just the lighting scenes.



Recommended Control4 products

- **MyHome.** If you'd like to control your home from your iOS or Android smartphones and tablets when you're away, download or install MyHome. See the MyHome documents at control4.com under Owners, Resources for details.

DOC-00121, Rev. A 2014 02-07 BN