## Adding Spotify Connect

Adding this service adds a Spotify Connect "device" which allows you to stream music from the Spotify app (on your phone, tablet, or laptop) to your Control4 system. Use of this service requires a Spotify Premium account.

You can add a single Spotify Connect device—that will play in any audio-capable room of the home—or multiple Spotify Connect devices (up to ten), allowing you to send independent streams to different speaker locations. Multiple Spotify Connect devices are ideal for family members who wish to have their own individual Spotify stream or for any location in the home where an independent Spotify stream is desired.\*

## To add a Spotify Connect device:

- 1. Select Add Service.
- 2. Select **Spotify Connect**.
- 3. Give the Spotify Connect device a name. This will be the device name that shows up in the Spotify app, allowing you to stream Spotify to Control4. If you wish to add multiple Spotify connect devices, give each device a unique name such as "Dad's Spotify" or "Kitchen Spotify".
- 4. Select **OK** to add the device, and then select **OK** to apply changes and reload the Control4 touch screen or Control4 app.

## To select the rooms in which a Spotify Connect device can be selected using a Control4 touch screen or app:

- 1. Select Edit Service.
- 2. Select the Spotify Connect device.
- 3. Select Show/Hide Service.
- 4. Check the box to choose the rooms where you want this Spotify Connect driver to be visible from a Control4 touch screen or app.

For detailed instructions on how to stream music from the Spotify app, select the **Spotify** icon from the Listen menu of any Control4 touch screen or app and view the "How to stream from Spotify" instructions. If you would like Spotify to start playing automatically in a room or group of rooms when you send audio to a Spotify Connect device, please contact your dealer who can set this up for you.

\*Independent streams require either separate Spotify Premium accounts or a Spotify Premium for Family plan (up to 6 accounts).

Copyright ©2018, Control4 Corporation. All rights reserved. Control4, the Control4 logo, the 4-ball logo, 4Sight, Control4 My Home, and Mockupancy are registered trademarks or trademarks of Control4 Corporation in the United States and/or other countries. All other names and brands may be claimed as the property of their respective owners. All specifications subject to change without notice. DOC-00399-A, 2018-08-23 DH

